



APPLIANCE CARE & MAINTENANCE

Refrigerator

- Clean off the condenser coils twice per year
- Clean and replace the gasket as needed
- Clean the interior to remove crumbs and spills
- Replace the ice maker or water dispenser water filter at least every 6 months

Range

- Clean stovetop regularly
- Clean oven monthly
- Clean range hood filters monthly
- Inspect oven door gaskets and heating elements quarterly

Over the Range Microwave

- Wipe up splatters and spills as they happen
- Clean filters monthly

Dishwasher

- Inspect and clean the spinning arms and make sure holes are not blocked
- Clean the edges and gaskets regularly
- Keep drain clear of debris or food particles

Washer

- Do not overload
- Make sure you're only using HE detergent in High Efficiency washers
- Wipe down drum, door, and gaskets weekly
- Leave door ajar after use

Dryer

- Clear lint trap with each use
- Deep clean chute with vacuum or long lint brush and scrub lint screen quarterly
- Clean exterior vent monthly
- Clean out exhaust vent yearly

Water Softener

- Check the salt level every 4-6 weeks and keep salt at about half full
- Refer to your owner's manual to ensure you're using the right salt
- Clean the brine tank once a year

Disposal

- Clean monthly with baking soda and vinegar
- Grind lemon or orange peel with ice cubes to refresh and sharpen blades
- Only run the disposal with water running